

1/7




FIG. 1

2/7





FIG. 2



Philips RC codes are
installed in this device
Do you want to change it?




FIG. 3

3/7



In the next screen tap
your brand in the list
If your brand is not
listed, press Search




FIG. 4




FIG. 5

4/7





FIG. 6



This brand has 4 RC code sets
Tap one or press Search to
step through all possibilities



FIG. 7

5/7




FIG. 8




FIG. 9

6/7



If your TV functions
properly, press Next,
otherwise press Back




FIG. 10




FIG. 11

7/7



If all buttons are
installed, press Next
Else press Back




FIG. 12




FIG. 13